

Wonder Wood - Maintenance and Care

Humidity

- Hardwood flooring is living and breathing long after it has come from the tree. Wonder Wood's HDPC core enhances the stability of the product but it is still important to control humidity within the required tolerances.
- The best way to do this is with a thermal hygrometer, these can be purchased in a variety of units. The intention is to have the ability to read the humidity level in your home at anytime of any season.
- Wonder Wood floors remain stable between 25% and 60% humidity. Less than 25% (dry climates) will cause wood to contract and shrink. As a result, gaps between boards will occur, and cracking can occur in severe circumstances.
- Hardwood floors living in relative humidity excess of 60% will take on moisture and will expand, causing overwood.

Cleaning

- Use a vacuum with a felt or brush head (without a beater bar) dust mop or sweep once a week or more if needed. A swivel head mop with a terry cloth attachment is recommended.
- When required use a recommended wood floor cleaner (such as Bona Kemi Hardwood Floor Cleaner, following manufacturers instructions) to clean your floor. Once a week is generally sufficient.
- Vinegar and water is not recommended.
- Never wax a pre finished floor.
- Never use any cleaning products other than those recommended for Hardwood and Laminate floors. These cleaning products should be purchased through the recommendation of your retailer.
- Never use cleaners containing any forms of oil.
- Factory finishes are produced to last many years of normal living, this includes the gloss level. By using products other than Hardwood and Laminate cleaners may have an adverse reaction with your finish and would not be covered by warranty.

Prevention

- Place walk off mats on the interior and exterior of doorway entrances, this will help trap dirt and grit from entering into your home. Additionally, mats in front of kitchen sinks, and high traffic areas are helpful. The backer should be a breathable material to prevent trapping moisture.
- Never use scouring products.
- Felt pads should be placed under the legs of all chairs and furniture in contact with the surface to prevent scuffing and scratching.
- Any furniture needed to be moved should be lifted. Do not slide furniture over the floor.

- Cleats, sports shoes and high heels can dent any floor surface; these types of shoes should be removed and left at the doorway.
- Pets nails should be trimmed regularly to ensure scratching is reduced.
- Wipe up any spills immediately with a soft moist cloth, starting at the edges of the spill and working your way toward the center. Immediately dry with a soft dry cloth.

Do's & Don'ts with Wonder Wood Flooring

DO: Sweep your floors regularly. Invest in a broom that features soft, fine bristles to trap dust and dirt. Dust mops can also be helpful in keeping dirt, dust, and grit under control.

DO: Damp mop your Wonder Wood Floor but do not saturate with water.

DO: Move your area carpets or throw rugs occasionally to maintain a uniform appearance in the floor's finish.

DO: Use non-marking barrel rubber casters instead of plastic or metal for office chairs.

DO: Be aware that high heels can dent a hardwood floor; leave them at the door.

DON'T: Leave spills unattended. Wonder Wood is highly resistant to topical moisture but spills should always be wiped up as soon as possible.

DON'T: Attempt to replace boards or any other types of repairs without seeking the advice and help of a professional; you may void your warranty.